

Venueinfo Rockefeller – Oslo Norway

Update: Okt 2014 ØB

- Venue:** Rockefeller Music Hall
- Venue type:** Club with 2 balconies, mainly standing audience.
- Capacity:** 1300 standing
- Address:** Torggata 16, N-0181 Oslo, Norway
Load in - Mariboegate
- Phone/Fax/Mail:** Switchboard (+47) 22 20 32 32
Prod. Office (analog) (+47) 22 03 48 18
Prod. Office (analog) (+47) 22 03 48 19
Prod. fax / Admin. Fax (+47) 22 11 04 69
e-mail post@rockefeller.no
web www.rockefeller.no
- Parking:** Must be arranged in advance. Shore power: 2x16A, 230V Schuko.
- Load in:** Street level, up a 15m steep ramp to 2nd floor, 15m push to stage.
- Stage:** 11m wide, 6m deep.
1,25m high (no fire curtain).
Clearance 6,9m to house rig (see drawings)
- Rigging:** Points can be made above the stage around concrete beams and a separate I-beam for touring productions.
House lighting rig flown by 4 x 1000Kg-travelling motors.
House PA flown by 2 x 1000Kg travelling motors
2 x 1250Kg travelling motors available for touring productions.
- House lighting:** 52 channels dimmer system, GrandMa 2 Light, Clay Paky Alpha spot QWO 800, Robe 575 wash, 60 single par64 - All cp-61. MDG hazer. 1 house follow spot, fixed position on balcony.
Full specs. : http://www.rockefeller.no/specs/light_specs_rockefeller.pdf
- Mixer position:** 10m from stage in front of balcony stairs, underneath the balcony, clearance 3,3m.
- House PA:** Midas Heritage 2000, EAW system: 8 x EAW KF750F, 4 x EAW KF755F, 4 x EAWSB750Fi, 8 x EAW SB1000z , CROWN amps.
Full specs: http://www.rockefeller.no/specs/sound_specs_rockefeller.pdf
- Power:** The power system in Rockefeller is the Delta system 230V.
The system has 3 phases + ground but no neutral.
Power needs must be arranged minimum two weeks in advance.
We charge a fee for transformers to get the Star system.
The Star system has 3 phases + ground and neutral.

Power points: 1 x 125A - 230V, 3 phases for in-house lights (Delta).
1 x 63 amp - 230V, 3 phases for in-house sound (Delta).

Again transformers may be used for Star (5 wire) power.

Available 400V Star:

1 x service, 3x90A, 400V, neutral and earth,

Connectors: Powerlock or 63A Cee-form.

1 x service, 3x44A, 400V, neutral and earth,

Connectors: Cee-form 63A or 32A

Dressing rooms: All rooms situated backstage. 1 x large lounge
2 x small rooms. 2 x toilets with sink and 1 x shower.
1 x medium size room with private toilet, sink, hot/cold water.

Production office: 1 x room situated backstage.
Production phone no's: +47 22 03 48 18/19.

Catering area: One medium room with kitchen facilities available at the back of the venue.

Standard running times:

Load in: As required

Doors: 20.00

Show: 21.30

Please note: No amplified noise or soundcheck before 17:00 on weekdays, due to shops and offices in the building.

Saturday and Sunday no noise before 14:00.

NOTE: Fire ails around the stage.
No stacking of equipment in these ails.
Smoke machine and pyro requires Fire chief. Pyro also requires permit from Fire dept. Please forward info.

Venue Manager
mail

Roar Gulbrandsen
roar@rockefeller.no

Booking
mail
phone

Vegard Engelsvoll
vegard@rockefeller.no
(+47) 22 03 48 14

Booking
mail
phone

Bo Hustoft
bo@rockefeller.no
(+47) 22 03 48 01

Booking
mail
phone

Joakim Throndsen
joakim@rockefeller.no
(+47) 22 03 48 26

Tech.manager
mail
phone

Ørjan Bjørnevik
orjan@rockefeller.no
(+47) 22 03 48 24