

Venueinfo Rockefeller – Oslo Norway

Update: Aug 2021

- Venue:** Rockefeller Music Hall
- Venue type:** Club with 2 balconies, mainly standing audience.
- Capacity:** 1300 standing
- Address:** Badstugata 2, N-0183 Oslo, Norway
Load in – Mariboegate 5B
- Contact info:** Switchboard (+47) 22 20 32 32
e-mail post@rockefeller.no
web www.rockefeller.no
- Parking:** Must be arranged in advance. Shore power: 2x16A, 230V Schuko.

EXCESSIVE IDLING OF TRUCKS AND BUSES IS AGAINST THE LAW – Because of the health and environmental risks. (Take care of the environment and next door neighbours while visiting our venue. Thanks!)
- Load in:** Street level, up a 15m steep ramp to 2nd floor, 15m push to stage.
- Stage:** 11m wide, 6m deep.
1,25m high (no fire curtain).
Clearance 5,94m to house rig
- Rigging:** Points can be made above the stage around concrete beams and a separate I-beam for touring productions.
House lighting rig flown by 4 x 1000Kg-travelling motors.
House PA flown by 2 x 1000Kg travelling motors
2 x 1250Kg travelling motors available for touring productions.
- House lighting:** 52 channels dimmer system, GrandMa 2 Light, Clay Paky Mythos, Clay Paky K10, 60 single par64, 4-Light Blinders, Atomic 3000, MDG hazer. 1 house follow spot.
Full specs. : http://www.rockefeller.no/specs/light_specs_rockefeller.pdf
- Mixer position:** 10m from stage in front of balcony stairs, underneath the balcony, clearance 3,3m.
- House PA:** Midas ProX/Pro2, EAW system: 8 x EAW KF750F, 4 x EAW KF755F, 4 x EAWSB750Fi, 8 x EAW SB1000z , CROWN amps.
Full specs: http://www.rockefeller.no/specs/sound_specs_rockefeller.pdf
- Power:** The power system in Rockefeller is the Delta system 230V.
The system has 3 phases + ground but no neutral.
Power needs must be arranged minimum two weeks in advance.

We charge a fee for transformers to get the Star system.
The Star system has 3 phases + ground and neutral.

Power points: 1 x 125A - 230V, 3 phases for in-house lights (Delta).
1 x 63 amp - 230V, 3 phases for in-house sound (Delta).

Again transformers may be used for Star (5 wire) power.
Available 400V Star:
1 x service, 3x90A, 400V, neutral and earth,
Connectors: Powerlock or 63A Cee-form.
1 x service, 3x44A, 400V, neutral and earth,
Connectors: Cee-form 63A or 32A

Dressing rooms: All rooms situated backstage. 1 x large lounge
2 x small rooms. 2 x toilets with sink and 1 x shower.
1 x medium size room with private toilet, sink, hot/cold water.

Production office: 1 x room situated backstage.

Catering area: One medium room with kitchen facilities available at the back of the venue.

Standard running times:

Load in: As required
Doors: 19:00 / 20.00
Show: 20:30 / 21.30

Please note: No amplified noise or soundcheck before 17:00 on weekdays, due to shops and offices in the building. Saturday and Sunday no noise before 14:00.

NOTE: Fire ails around the stage.
No stacking of equipment in these ails.
Smoke machine and pyro requires Fire chief. Pyro also requires permit from Fire dept. Please forward info.

| | | | |
|--------------------------------------|---|---------------------------------|---|
| Venue Manager mail | Roar Gulbrandsen roar@rockefeller.no | Booking mail phone | Vegard Engelsvoll vegard@rockefeller.no (+47) 22 03 48 14 |
| Booking mail phone | Bo Hustoft bo@rockefeller.no (+47) 22 03 48 01 | Booking mail phone | Joakim Throndsen joakim@rockefeller.no (+47) 22 03 48 26 |
| Tech.manager mail phone | Ørjan Bjørnevik orjan@rockefeller.no (+47) 22 03 48 24 | | |