

Venueinfo John Dee live club - Oslo Norway

A division of the Rockefeller Music Hall Company

Update: Okt 2014

- Venue:** John DEE Live Club
- Venue type:** Club with mainly standing audience
- Capacity:** 400 standing
- Address:** Torggata 16, N-0181 Oslo, Norway
Load in: Mariboesgate
- Phone/Fax/Mail:** Switchboard (+47) 22 20 32 32
Prod. fax / Admin. fax (+47) 22 11 04 69
e-mail post@rockefeller.no
web www.rockefeller.no
- Parking:** Must be arranged in advance. 15m space outside venue.
- EXCESSIVE IDLING OF TRUCKS AND BUSES IS AGAINST THE LAW Because of the health and environmental risks. (Take care of the environment and next door neighbours while visiting our venue. Thanks!)
- Load-in:** Street level, 15 m push to stage.
- Stage** 7m wide, 4,5m deep, 0,7m high, 3,4m clearance to ceiling.
- In-house lights:** Please see specs. http://www.rockefeller.no/specs/light_specs_johndee.pdf
- In-house PA system:** Please see specs. http://www.rockefeller.no/specs/sound_specs_johndee.pdf
- Power, in general:** Delta system (3 phases + ground, no neutral) 230V
- Power-sound/backl.:** 63A - 230V, 3 phases + ground, no neutral (PA and monitors)
4 x 16A single phase Shuko (Backline, FOH, splitters)
- Power - Lights:** 80A – 230V, 3 phases + ground (house-rig. Not available for ext. prod.)
32A – 230V, 3 phases + ground (house-rig. Not available for ext. prod.)
- Power external prod:** 32A – 230V, 3 phases + ground
63A – 230V, 3 phases + ground
63A – 230V, 3 phases + ground
Transformers may be used for Star (5 wire) power. This will give you:
1xservice, 3x32A, 400V, neutral and earth, CEE connector.
- Dressing rooms:** Two large rooms situated one floor above the venue with
1 x shower, 1 toilet & sink & mirror, well furnished for 10 people.
230V Power outlets for tuning etc. Lockable. Keys to be delivered.

Access to stage area through stairs.

Standard running times:

Load in: As required
Doors: 20.00
Show: 21.30

Please note: No amplified noise or soundcheck before 17:00 on weekdays due to shops and offices in the building. Saturday and Sunday, no noise before 14:00

Curfew: approx. 01:00 am

Venue Manager:
mail Roar Gulbrandsen
roar@rockefeller.no

Booking:
mail Vegard Engelsvoll
vegard@rockefeller.no
phone (+47) 22 03 48 14

Booking
mail Bo Hustoft
bo@rockefeller.no
phone +47 22 03 48 01

Booking
mail Joakim Throndsen
joakim@rockefeller.no
phone (+47) 22 03 48 26

Tech. Manager:
mail Ørjan Bjørnevik
orjan@rockefeller.no
phone (+47) 22 03 48 24
cellular (+47) 90 01 20 17