

## Venueinfo Rockefeller – Oslo Norway

Update: Mars 2011 ØB

- Venue:** Rockefeller Music Hall
- Venue type:** Club with 2 balconies, mainly standing audience.
- Capacity:** 1300 standing
- Address:** Torggata 16, N-0181 Oslo, Norway  
Load in - Mariboegate
- Phone/Fax/Mail:** Switchboard (+47) 22 20 32 32  
Prod. Office (analog) (+47) 22 03 48 18  
Prod. Office (analog) (+47) 22 03 48 19  
Prod. fax / Admin. Fax (+47) 22 11 04 69  
e-mail [post@rockefeller.no](mailto:post@rockefeller.no)  
web [www.rockefeller.no](http://www.rockefeller.no)
- Parking:** Must be arranged in advance. Shore power: 2x16A, 230V Schuko.
- Load in:** Street level, up a 15m steep ramp to 2nd floor, 15m push to stage.
- Stage:** 11m wide, 6m deep.  
1,25m high (no fire curtain).  
Clearance 6,9m to house rig (see drawings)
- Rigging:** Points can be made above the stage around concrete beams and a separate I-beam for touring productions.  
House lighting rig flown by 4 x 800Kg-travelling motors.  
House PA flown by 2 x 1000Kg travelling motors  
2 x 1250Kg travelling motors available for touring productions.
- House lighting:** 52 channels dimmer system, Pearl 2004 mixer, Clay Paky Alpha spot HPE 1500, Robe 575 wash, 70 single par64. All cp-61. 1 cracked oil machine - MDG  
1 house follow spot, fixed position on balcony.  
Full specs. : [http://www.rockefeller.no/specs/light\\_specs\\_rockefeller.pdf](http://www.rockefeller.no/specs/light_specs_rockefeller.pdf)
- Mixer position:** 10m from stage in front of balcony stairs, underneath the balcony, clearance 3,3m.
- House PA:** Midas Heritage 2000, EAW system: 8 x EAW KF750F, 4 x EAW KF755F, 4 x EAWSB750Fi, 8 x EAW SB1000z , CROWN amps.  
Full specs: [http://www.rockefeller.no/specs/sound\\_specs\\_rockefeller.pdf](http://www.rockefeller.no/specs/sound_specs_rockefeller.pdf)
- Power:** The power system in Rockefeller is the Delta system 230V.  
The system has 3 phases + ground but no neutral.  
We charge a fee for transformers to get the Star system.  
The Star system has 3 phases + ground and neutral.

Star will give 230V between any phase and neutral and 380V between any two phases.

**Power points:** 1 x 125A - 230V, 3 phases for lights (Delta), stage left.  
1 x 63 amp - 230V, 3 phases for sound (Delta), stage left.  
Again transformers may be used for Star (5 wire) power.  
This will give you:  
1 x service, 3x140A, 400V, neutral and earth, Cam-lok for lights.  
1 x service, 3x63A, 400V, neutral and earth, Cee-form for sound.

**Dressing rooms:** All rooms situated backstage. 1 x large lounge  
2 x small rooms. 2 x toilets with sink and 1 x shower.  
1 x medium size room with private toilet, sink, hot/cold water.

**Production office:** 1 x room situated backstage.  
Production phone no's: +47 22 03 48 18/19.

**Catering area:** One medium room with kitchen facilities available at the back of the venue.

**Standard running times:**

Load in: As required  
Doors: 20.00  
Show: 21.30

**Please note: No amplified noise or soundcheck before 17:00 on weekdays, due to shops and offices in the building. Saturday and Sunday no noise before 14:00.**

**NOTE:** Fire ails around the stage.  
**No stacking of equipment in these ails.**  
**Smoke machine and pyro requires Fire chief. Pyro also requires permit from Fire dept. Please forward info.**

Venue Manager  
mail Roar Gulbrandsen  
[roar@rockefeller.no](mailto:roar@rockefeller.no)

Booking:  
mail Vegard Engelsvoll  
[vegard@rockefeller.no](mailto:vegard@rockefeller.no)  
phone (+47) 22 03 48 14

Booking  
mail Bo Hustoft  
[bo@rockefeller.no](mailto:bo@rockefeller.no)  
phone (+47) 22 03 48 01

Tech.manager  
mail Ørjan Bjørnevik  
[orjan@rockefeller.no](mailto:orjan@rockefeller.no)  
phone (+47) 22 03 48 24  
cellular (+47) 90 01 20 17